

Nikola Tesla user guide and maintenance manual

NikolaTesla Switch's smart sensor technology distinguishes between fume quality and type of cooking. This product is completely automatic, automatically setting the required aspiration speed.



How do I carry out installation and maintenance?

Which accessories are compatible?

Read the guide:

With **NikolaTesla** optimum product maintenance is guaranteed fast and easy. By removing the grease filter, which is dishwasher safe*, from the central grid, you can safely and fully clean the inside of the appliance. A special internal valve drains any eventual liquid spillage. The smooth continuous surface of the hob is not only a design detail, but it is also fast and easy to clean.

Choose accessories according to the type of Nikola Tesla that you have in your kitchen:

FILTERING VERSION

If you own the filtering version you can find related products such as pipes and fittings on our site



BUY THE PRODUCTS ON OUR SHOP

San qr code for more informations



INSTALLATION USE AND MAINTENANCE VIDEO

San qr code for more informations

ASPIRATING VERSION

If you own the aspirating version you can find related products, such as pipes and fittings on our site



BUY THE PRODUCTS ON OUR SHOP

San qr code for more informations



INSTALLATION USE AND MAINTENANCE VIDEO

San qr code for more informations

By installing this KIT, air will be filtered and purified before being supplied back into the room through the ceramic filters, which are included in the package (4 ceramic filters KIT0120952) solely compatible with NikolaTesla.



BUY* HERE

Scan qr code for more informations

shop.elica.com/en/accessori/KIT0130427.html

By installing this KIT, air will be filtered and purified before being supplied back into the room through the ceramic filters, which are included in the package (4 ceramic filters KIT0120952) solely compatible with NikolaTesla.

FILTER CHARACTERISTICS:

Filter size: 83x51x21 cm

Filter type: Ceramic

Finish: Black glass

Odor filtering efficiency: 80%

Mode: filtering

FILTER MAINTENANCE:

The filters are renewable in the oven at 200° for 45 min (repeat every 2-3 months for proper maintenance).

***Caution:** The grease filter must be washed by hand or in the dishwasher at (65°C) with suitable detergents (rapid cycle). When washed in the dishwasher, the grease filter color may fade, this does not in any way affect its filtering characteristics. It must be washed at least once a month or, in any case, as needed.